

PowerFlex® T° Hi Viz Yellow™

80-400

General-purpose
knitted and
dipped glove

Excellent insulation
and comfortable handling
in cold conditions



Ansell's PowerFlex® T° Hi Viz Yellow™ 80-400 is a general-purpose glove that is designed to provide outstanding insulation from cold conditions, as well as high comfort and grip. A further addition to the PowerFlex® range, this new

glove combines a thermal terry loop acrylic liner with a naturally insulating latex coating, ensuring excellent protection against the cold. This glove provides comfort and protection for the wearer in temperatures down to as low as -30°C.

Ansell

Recommended usage

Handling and carrying in cold conditions for applications in:

- Transport and construction
- Refrigeration and cooling plants
- Perishables warehousing
- Public maintenance
- Refuse collection
- Shipping and receiving.

Designed for the cold

The PowerFlex® T° Hi Viz Yellow™ is designed specifically to keep hands warm in colder environments, thanks to a thermal terry loop acrylic liner that provides excellent insulation against the cold. This highly insulating liner combined with the natural insulation provided by the latex coating ensures comfortable working conditions down to temperatures as low as -30°C.

Extra visibility for improved safety

With a terry loop acrylic liner that is bright yellow in colour, the PowerFlex® T° Hi Viz Yellow™ glove offers extra high visibility in low or poor light conditions. This extra visibility brings additional safety for external workers when it's getting dark.

Specifications

Ref.	Type	Style	EN Size	Length	Colour
80-400	Palm-coated, knitted glove	Knitwrist	7-11	255-295 mm	Bright yellow liner + blue coating

Packaging

12 pairs per polybag, 12 polybags per carton.

C E 0493



X231
EN388



X2XXXX
EN407



020
EN511

Ansell

Ansell Limited is a global leader in barrier protective products. With operations in the Americas, Europe and Asia, Ansell employs more than 11,000 people worldwide and holds leading positions in the natural latex and synthetic polymer glove and condom markets. Ansell operates in three main business segments: Occupational Healthcare, supplying hand protection to the industrial market; Professional Healthcare, supplying surgical and examination gloves to healthcare professionals; and Consumer Healthcare, supplying condoms and consumer hand protection. Information on Ansell and its products can be found at <http://www.ansell.eu>

PowerFlex® T° Hi Viz Yellow™ 80-400 is a registered trademark of Ansell Ltd. or one of its affiliates.

PowerFlex® T° Hi Viz Yellow™ 80-400

General-purpose
knitted and
dipped glove

the skin, even after repeated wear. And thanks to a precisely controlled forming and dipping process, the glove's latex coating is of consistent thickness and supports the hand's natural dexterity.

Because the latex coating is only applied on the palm and thumb, the back of the glove breathes to give the wearer all-day comfort. The latex coating also absorbs pressure when handling heavy objects, adding to the wearer's comfort. Finally, a continuous cuff ensures additional protection as well as a secure hold on the wrist.

Sure grip in all conditions

The glove's latex coating possesses a raised crinkle finish which gives excellent grip in both dry and wet conditions. This coating also covers the thumb, ensuring even better grip and providing the increased protection necessary for heavy handling applications. The coating also reduces dirt and moisture penetration, helping to keep the glove clean longer and extending glove life.

High comfort and flexibility

Ansell's high-precision manufacturing technology ensures that the glove's seamless knitted liner offers superb fit and flexibility as well as avoiding irritation. The inside of the lining remains soft against